



<b>Tool Box Vehicle Guide</b>  Add (B) to end of part number for Black Powder Coat Finish - Numbers with plus sign (+) are not available in Black	Single Lid																							
	Low-Pro				Standard								Deep											
	Scout	Scout Narrow	Garri son Narrow	Scout	Garri son								EXTREME			Garri son	Garri son Wide	EXTREME Wide						
					40201	40202	40002	41012	40101	40102	41001	41003	41010	41007	41004				41009	41011	41013	41005	56001	56002
<b>Chevy/GMC</b>																								
70-10 Full Size	X		X	X	X		X									X				X			X	X
07-10 Full Size 5.8' Bed	X		X	X	X		X									X								
88-02 Full Size Sportside									X															
04-09 Canyon/Colorado (Except Crew)									X							X						X		
04-09 Canyon/Colorado Crew Cab																X						X		
92-06 S-10/S-15 (Except Crew Cab)		X			X		X										X	X						
01-04 S-10/S-15 Crew Cab																								
<b>Dodge</b>																								
09 Ram 1500	X		X	X	X		X									X				X			X	X
09 Ram 1500 5.6' Bed	X		X	X	X		X									X				X				
02-08 Ram	X		X	X	X					X						X				X			X	
94-02 Ram	X		X	X	X		X									X				X			X	X
78-93 Full Size	X		X	X	X		X									X				X			X	X
05-09 Dakota Crew Cab															X							X		
05-09 Dakota Club Cab										X												X		
87-04 Dakota (Except Crew)										X														
<b>Ford</b>																								
04-09 F150 (except SuperCrew)	X		X	X	X		X									X				X			X	X
04-09 F150 SuperCrew 5.6' Bed			X	X																				
06-09 F150 SuperCrew 6.5' Bed	X		X	X	X		X									X				X			X	X
97-03 F150/F250 (Light Duty)	X		X	X	X		X									X				X			X	X
01-03 F150 SuperCrew Cab			X	X																				
97-08 F150 Flareside															X									
87-96 F Series	X		X	X	X		X									X				X			X	X
87-96 F150 Flareside									X															
99-09 Super Duty	X				X					X						X				X			X	
97-98 F250/F350 Heavy Duty	X		X		X		X									X				X			X	X
83-09 Ranger (Except Edge)		X				X	X					X						X	X					
93-01 Ranger Splash (Except Edge)													X											
<b>Toyota</b>																								
07-10 Tundra	X		X	X	X		X									X				X			X	X
00-06 Tundra															X									
93-99 T100															X									
05-09 Tacoma - no crew									X							X						X		
05-09 Tacoma Crew Cab															X							X		
89-04 Tacoma		X					X					X					X	X						

This is a general guide - please check application using tool box measurements from pages 34-38 for verification prior to ordering product paying close attention to bed rail track systems on newer vehicles, bed liners, wheel well openings, extra short and step side beds.



<b>Tool Box Vehicle Guide</b>  <i>Add (B) to end of part number for Black Powder Coat Finish - Numbers with plus sign (+) are not available in Black</i>	Gull Wing					Side Mount						Top Sider			RV Chest			Wheel Well						
	Standard				Deep	Garrison			EXTREME			Garrison												
	Scout		Garrison			Garrison	Full Size 48"	Full Size 60"	Full Size 72"	Down Size 48"	48" EXtra Wide	56" EXtra Wide	72" EXtra Wide	72"	90"	96"	60" Slant Front	60" Slant Sides	55" Slant Front	44"	36"	Med/um	Large	
	40301	40302	43001	43003	43005	43002	42001	42002	42003	42006	56201	56202	56203	46001+	46002+	46003+	44001	44008	44002	44004	44003	42004	42005	
<b>Chevy/GMC</b>																								
70-10 Full Size	X		X			X	X	X	X		X	X	X	X	X	X		X	X	X			X	
07-10 Full Size 5.8' Bed	X		X				X				X													
88-02 Full Size Sportside							X	X	X		X	X	X	X						X	X			
04-09 Canyon/Colorado (Except Crew)							X			X										X	X	X		
04-09 Canyon/Colorado Crew Cab																								
92-06 S-10/S-15 (Except Crew Cab)		X			X					X										X	X	X		
01-04 S-10/S-15 Crew Cab										X											X	X		
<b>Dodge</b>																								
09 Ram 1500	X		X			X	X	X	X		X	X	X	X	X			X	X	X			X	
09 Ram 1500 5.6' Bed	X		X				X	X	X		X	X	X	X	X					X	X		X	
02-08 Ram	X		X	X		X	X	X	X		X	X	X	X	X		X			X	X		X	
94-02 Ram	X		X	X		X	X	X	X		X	X	X	X	X		X			X	X		X	
78-93 Full Size	X		X			X	X	X	X		X	X	X	X	X		X			X	X		X	
05-09 Dakota Crew Cab																								
05-09 Dakota Club Cab							X		X											X	X	X		
87-04 Dakota (Except Crew)							X		X											X	X	X		
<b>Ford</b>																								
04-09 F150 (except SuperCrew)	X		X			X	X	X	X		X	X	X	X	X		X	X	X	X			X	
04-09 F150 SuperCrew 5.6' Bed							X	X	X		X	X	X	X	X					X	X	X	X	
06-09 F150 SuperCrew 6.5' Bed	X		X			X	X	X	X		X	X	X	X	X		X			X	X	X	X	
97-03 F150/F250 (Light Duty)	X		X			X	X	X	X		X	X	X	X	X		X			X	X	X	X	
01-03 F150 SuperCrew Cab							X	X	X		X	X	X	X	X					X	X	X		
97-08 F150 Flareside							X	X	X		X	X	X	X	X					X	X			
87-96 F Series	X		X			X	X	X	X		X	X	X	X	X		X			X	X	X	X	
87-96 F150 Flareside							X	X	X		X	X	X	X	X					X	X			
99-09 Super Duty	X		X	X		X	X	X	X		X	X	X	X	X		X			X	X	X	X	
97-98 F250/F350 Heavy Duty	X		X			X	X	X	X		X	X	X	X	X		X			X	X	X	X	
83-09 Ranger (Except Edge)		X			X				X												X	X	X	
93-01 Ranger Splash (Except Edge)									X												X	X		
<b>Toyota</b>																								
07-10 Tundra	X		X			X	X	X	X		X	X	X	X	X					X	X	X	X	
00-06 Tundra							X	X	X		X	X	X	X	X					X	X	X	X	
93-99 T100							X	X	X		X	X	X	X	X					X	X	X	X	
05-09 Tacoma		X			X				X												X	X	X	
05-09 Tacoma Crew Cab																								
89-04 Tacoma		X			X				X												X	X	X	

This is a general guide - please check application using tool box measurements from pages 34-38 for verification prior to ordering product paying close attention to bed rail track systems on newer vehicles, bed liners, wheel well openings, extra short and step side beds.



<b>Tool Box Vehicle Guide</b>  <i>Add (B) to end of part number for Black Powder Coat Finish - Numbers with plus sign (+) are not available in Black</i>	<b>EXTREME XPL Single Lid</b>																		
	<b>Low-Pro</b>						<b>Standard</b>						<b>Chests</b>						
	<i>Full Size</i>	<i>Full size Deep</i>	<i>FS Narrow &amp; Deep</i>	<i>FS Wide &amp; Deep</i>	<i>Down Size Narrow</i>	<i>DS Narrow &amp; Deep</i>	<i>Full Size</i>	<i>Full Size Deep</i>	<i>FS Wide &amp; Deep</i>	<i>Mid Size</i>	<i>Down Size</i>	<i>Down Size Import</i>	<i>Side Mount 48"</i>	<i>Side Mount 56"</i>	<i>Side Mount 78"</i>	<i>60" RV Slant Front</i>	<i>60" RV Slant Sides</i>	<i>44" Utility</i>	<i>36" Utility</i>
	57501	57502	57512	57508	57525	57526	57001	57002	57008	57007	57003	57009	57201	57202	57203	57401	57408	57404	57403
<b>Chevy/GMC</b>																			
70-10 Full Size	X	X	X	X			X	X	X				X	X	X	X		X	X
07-10 Full Size 5.8' Bed	X		X				X						X						
88-02 Full Size Sportside													X	X	X			X	X
04-09 Canyon/Colorado (Except Crew)									X				X					X	X
04-09 Canyon/Colorado Crew Cab																			
92-06 S-10/S-15 (Except Crew Cab)					X	X				X								X	X
01-04 S-10/S-15 Crew Cab					X	X													X
09 Ram 1500	X	X	X	X			X	X	X				X	X	X			X	X
09 Ram 1500 5.6' Bed	X		X				X						X	X	X			X	X
02-08 Ram	X	X	X				X	X					X	X	X		X	X	X
94-02 Ram	X	X	X	X			X	X	X				X	X	X	X		X	X
78-93 Full Size	X	X	X	X			X	X	X				X	X	X	X		X	X
05-09 Dakota Crew Cab																			
05-09 Dakota Club Cab									X				X					X	X
87-04 Dakota (Except Crew)									X				X					X	X
04-09 F150 (except SuperCrew)	X	X	X	X			X	X	X				X	X	X	X		X	X
04-09 F150 SuperCrew 5.6' Bed			X										X	X				X	X
06-09 F150 SuperCrew 6.5' Bed	X	X	X	X			X	X	X				X	X	X			X	X
97-03 F150/F250 (Light Duty)	X	X	X	X			X	X	X				X	X	X	X		X	X
01-03 F150 SuperCrew Cab			X										X	X				X	X
97-08 F150 Flareside													X	X	X			X	X
87-96 F Series	X	X	X	X			X	X	X				X	X	X	X		X	X
87-96 F150 Flareside													X	X	X			X	X
99-09 Super Duty	X	X		X			X	X	X				X	X	X		X	X	X
97-98 F250/F350 Heavy Duty	X	X		X			X	X	X				X	X	X	X		X	X
83-09 Ranger (Except Edge)					X	X					X	X						X	X
93-01 Ranger Splash (Except Edge)																		X	X
07-10 Tundra	X	X	X	X			X	X	X				X	X	X			X	X
00-06 Tundra													X	X	X			X	X
93-99 T100													X	X	X			X	X
05-09 Tacoma									X									X	X
05-09 Tacoma Crew Cab																			
89-04 Tacoma					X	X					X	X						X	X

This is a general guide - please check application using tool box measurements from pages 34-37 for verification prior to ordering product paying close attention to bed rail track systems on newer vehicles, bed liners, wheel well openings, extra short and step side beds.