



## Bracket Cover

IN 595

### Tools Required

- Diagonal Cutting Pliers
- Tape Measure
- Drill with Phillip Bit

### Bracket Covers U channel plastic (Not End Caps)



- 1) For a Ford Super Duty truck notch top 1" x 1" cutting with diagonal cutter nipping about 1/4" at a time, or cut with saw if available.

**Use (2) self tapping screws to secure to bracket.**



- 2) For a GM truck cut down to 2 3/4" with diagonal cutter nipping about 1/4" at a time, or cut with saw if available.

**Use (2) self tapping screws to secure to bracket.**

**Ford F150 and Ram trucks do not require plastic covers**



## Bracket Cover

IN 595

### General Motors Truck



### Ford Super Duty Truck

