

## FORD DUALY MUD FLAP INSTALLATION INSTRUCTIONS

READ ENTIRE INSTRUCTION SHEET BEFORE INSTALLING MUD FLAPS TO ENSURE A PROPER INSTALLATION.

- STEP 1 FASTEN MUD FLAPS TO THE BRACKETS USING 5/16" X 1" BOLTS, NUTS, FLAT WASHERS AND LOCK WASHERS.
- STEP 2.) POSITION THE BRACKET UP TO THE BED PINCH WELD. USING THE BRACKET AS A GUIDE, MARK AND DRILL 11/32" HOLE'S.
- STEP 3.) FASTEN THE BRACKET TO THE BED PINCH WELD USING 5/16" X 1" BOLTS, NUTS, AND LOCK WASHERS.
- STEP 4.) FASTEN ONE END OF THE 20" STRAP TO THE OUTER MUD FLAP BOLT, BETWEEN THE BRACKET AND THE FLAP.
- STEP 5.) FASTEN THE OTHER END OF THE STRAP TO A EXISTING BOLT, WHICH FASTEN'S THE DUALY FENDER TO THE VEHICLE.

REPEAT ON OTHER SIDE.

