

99-C FORD DUALY MUD FLAP INSTALLATION INSTRUCTIONS

**READ ENTIRE INSTRUCTION SHEET BEFORE INSTALLING MUD
FLAPS TO ENSURE A PROPER INSTALLATION.**

- STEP 1.) USING THE 5/16" X 1" BOLT, NUT, AND SPLIT WASHERS TO FASTEN RUBBER FLAP TO THE BRACKET AT EACH END.
- STEP 2.) USING THE BRACKET AS A GUIDE MARK AND DRILL TWO 1 1/32 HOLES THROUGH BED PINCH WELD
- STEP 3.) FASTEN THE BRACKET TO THE BED PINCH WELD USING TWO 3/16" X 1" BOLT, NUT, AND SPLIT WASHERS.
- STEP 4.) FASTEN THE MIDDLE BRACKET BOLT THROUGH THE FENDER LINER AND FENDER BRACE. TO ACCOMPLISH THIS DRILL AN 1 1/32" CLEAR HOLE USING THE MIDDLE SLOT AS A GUIDE. FASTEN WITH A 5/16" X 1" BOLT, NUT, AND SPLIT WASHER.

